

1 Before driving

1-1. Hybrid system

Hybrid system.....	26
Hybrid system precautions	29
Energy monitor/ consumption screen	34
Hybrid vehicle driving tips.....	39

1-2. Key information

Keys	41
------------	----

1-3. Opening, closing and locking the doors

Smart access system with push-button start	46
Wireless remote control.....	57
Side doors	61
Back door	64

1-4. Adjustable components (seats, mirrors, steering wheel)

Front seats	75
Rear seats	80
Driving position memory	84
Head restraints.....	87
Seat belts	89

Steering wheel.....	97
---------------------	----

Anti-glare inside rear view mirror	99
---	----

Outside rear view mirrors.....	100
--------------------------------	-----

1-5. Opening and closing the windows and moon roof

Power windows.....	103
Moon roof	106

1-6. Refueling

Opening the fuel tank cap.....	110
--------------------------------	-----

1-7. Theft deterrent system

Immobilizer system	115
Alarm.....	117
Theft prevention labels	119

1-8. Safety information

Correct driving posture	120
SRS airbags	122
Front passenger occupant classification system.....	134
Child restraint systems	139
Installing child restraints.....	143

2 When driving

2-1. Driving procedures

Driving the vehicle.....	156
Power (ignition) switch.....	166
Hybrid transmission.....	171
Turn signal lever.....	179
Parking brake.....	180
Horn.....	181

2-2. Instrument cluster

Gauges and meters.....	182
Indicators and warning lights.....	185
Multi-information display.....	189
Head-up display.....	195

2-3. Operating the lights and windshield wipers

Headlight switch.....	200
Automatic High Beam.....	205
Fog light switch.....	211
Windshield wipers and washer.....	213
Rear window wiper and washer.....	218
Headlight cleaner switch.....	219

2-4. Using other driving systems

Cruise control.....	220
Dynamic radar cruise control.....	224
Intuitive parking assist.....	235
Electronically modulated air suspension.....	242
Rear view monitor system (rear view mirror-attached type).....	248
Driving assist systems.....	252
Hill-start assist control.....	258
Pre-Collision System.....	260

2-5. Driving information

Utility vehicle precautions.....	264
Cargo and luggage.....	269
Vehicle load limits.....	273
Winter driving tips.....	274
Trailer towing (AWD models with towing package).....	278
Trailer towing (2WD models and AWD models without towing package).....	291
Dinghy towing.....	292

3 Interior features

3-1. Using the air conditioning system and defogger

Automatic air conditioning system	296
Rear window defogger switch.....	303
Windshield wiper de-icer	304

3-2. Using the audio system

Audio system	305
Using the radio.....	309
Using the CD player.....	319
Playing MP3 and WMA discs.....	329
Operating an iPod® player....	339
Operating a USB memory player	347
Optimal use of the audio system.....	356
Using the AUX adapter	359
Using the steering wheel audio switches	361

3-3. Using the Bluetooth® audio system

Bluetooth® audio system	364
Using the Bluetooth® audio system.....	367
Operating a Bluetooth® enabled portable player	372
Setting up a Bluetooth® enabled portable player	376
Bluetooth® audio system setup	383

3-4. Using the hands-free phone system (for mobile phones)

Hands-free system for mobile phones	384
Using the hands-free system (for mobile phones).....	388
Making a phone call.....	396
Setting a mobile phone.....	401
Security and system setup	407
Using the phone book.....	411

3-5. Using the interior lights

Interior lights list.....	418
• Interior lights	419
• Personal lights	419

3-6. Using the storage features

List of storage features.....	421
• Glove box	422
• Bottle holders/ door pockets	423
• Cup holders.....	424
• Console box.....	426
• Auxiliary boxes.....	428
• Under tray	429

3-7. Other interior features

Sun visors.....	430
Vanity mirrors.....	431
Clock.....	432
Outside temperature display (vehicles without a navigation system)	433
Multi-display light control (vehicles without a navigation system)	434
Power outlets.....	435
Seat heaters and ventilators.....	438
Armrest	440
Coat hooks	441
Floor mat.....	442
Luggage compartment features.....	443
Garage door opener.....	447
Compass.....	453

4 Maintenance and care

4-1. Maintenance and care

Cleaning and protecting the vehicle exterior.....	458
Cleaning and protecting the vehicle interior	461

4-2. Maintenance

Maintenance requirements	464
General maintenance.....	466
Emission inspection and maintenance (I/M) programs	470

4-3. Do-it-yourself maintenance

Do-it-yourself service precautions.....	471
Hood	474
Positioning a floor jack.....	475
Engine compartment.....	477
12-volt battery.....	489
Tires	496
Tire inflation pressure.....	505
Wheels	510
Air conditioning filter.....	512
Electronic key battery	515
Checking and replacing fuses	517
Headlight aim	533
Light bulbs.....	536

5 When trouble arises

5-1. Essential information

Emergency flashers.....	556
If your vehicle needs to be towed	557
If you think something is wrong	563
Event data recorder	564

5-2. Steps to take in an emergency

If a warning light turns on or a warning buzzer sounds... ..	566
If a warning message is displayed.....	575
If you have a flat tire.....	596
If the hybrid system will not start.....	610
If the shift lever cannot be shifted from P	612
If you lose your keys	613
If the electronic key does not operate properly	614
If the vehicle 12-volt battery is discharged	617
If your vehicle overheats	620
If the vehicle becomes stuck.....	625

6 Vehicle specifications

6-1. Specifications

Maintenance data (fuel, oil level, etc.).....	628
Fuel information.....	640
Tire information.....	643

6-2. Customization

Customizable features.....	656
----------------------------	-----

6-3. Initialization

Items to initialize	665
---------------------------	-----

7 For owners

Reporting safety defects for U.S. owners.....	668
Seat belt instructions for Canadian owners (in French).....	669

Index

Abbreviation list 674

Alphabetical index..... 676

What to do if... 686

1

2

3

4

5

6

7